

## *Varian 979 Leak Detector Quick Reference Guide*

### **Front Panel & Controls**

#### Startup

1. Connect to AC power, turn on rear power control switch.
2. Check that the test port is connected or blank-off cap is in place.
3. Watch for SYSTEM READY to appear on front screen.
4. Set the little Key Switch to RUN
5. Touch screen will show SYSTEM PRESSURE WAIT for a short period
6. Then FILAMENT WAIT appears when the filament is being lit
7. HOLD, then STABILIZATION WAIT appears for up to 5 minutes
8. OFFSET WAIT appears on the screen, and the system will set an OFFSET value
9. Finally, HOLD and SYSTEM READY

...



**800-910-4356**